

1. Attached the top arm on the nipple then secure by bube.
2. Screw the nipple 2 into the poly pan and attached the arm on the nipple then secure by small finial.
3. Screw the nipple 3 into the coupler then secure by hex nut.
4. Attached glass and cap on the nipple then secure by finial.

